

CODING
- 124022



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

nesthouz.com

Read the instructions carefully. Remove all the wrappings , staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

CAUTION
KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	PHOTO	HARDWARE NAME	QTY
(A)		JCBC SCREW M6 X 80MM (RB)	9 (+2 extra)
(B)		JCBC SCREW M6 X 50MM (RB)	4 (+1 extra)
(C)		JCBC SCREW M6 X 35MM (RB)	4 (+1 extra)
(D)		SCREW PIN 15 X 15MM	4 (+1 extra)
(E)		SPRING WASHER 5/16" (RB)	17 (+2 extra)
(F)		FLAT WASHER M6 X 13MM (RB)	13 (+2 extra)
(G)		WOOD DOWEL M10 X 30MM	14 (+2 extra)
(H)		PH M4 X 32MM (BLACK)	3 (+1 extra)
(I)		ALLEN KEY M4 (BALL SHAPE)	1

ITEM	PHOTO	PARTS NAME	QTY
①		TABLE TOP	1
②		TABLE LEG (L & R)	2
③		APRON	1
④		LEG SUPPORTER	1
⑤		SELF BASE	1
⑥		POST BAR	2
⑦		TOP RAIL	1

CODING
- 124022



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

nesthouz.com

