

CODING
-131138



ISO 9001:2015
Reg. No. 000435-I-MY-I-QMS

nesthouz.com

Read the instruction carefully. Remove all the wrapping material, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches.

CAUTION

KEEP ALL THE PARTS OUT OF REACH OF CHILDREN.

ITEM	PHOTO	HARDWARE NAME	QTY
(A)		JCBC BOLT M6 X 50MM (BLK)	4 (+1 extra)
(B)		JCBC BOLT M6 X 40MM (BLK)	7 (+1 extra)
(C)		SPRING WASHER 5/16" (BLK)	11 (+2 extra)
(D)		SCREW PIN	4 (+1 extra)
(E)		WOOD DOWEL M10 x 30	4 (+1 extra)
(F)		ALLEN KEY M4	1

ITEM	PHOTO	PART NAME	QTY
(1)		TABLE TOP	1
(2)		TABLE LEG L/R	2
(3)		SHELVE BIG	1
(4)		SHELVE SMALL	1

CODING
-131138



ISO 9001:2015
Reg. No. 000435-1-MY-1-QB5

nesthouz.com

