HOBBIT WARRANTY & ASSEMBLY GUIDE

CODING

- -1329014
- -1329015



ISO 9001:2015

nesthouz.com

Read the instruction carefully. Remove all the wrapping material. Staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches

CAUTION KEEP ALL THE PARTS OUT REACH OF CHILDREN

TEM	HARDWARE LIST		QTY	ΩTY
1	WOOD DOWEL MID X 35MM		8	
2	ICBC SCREW M6 x 40MM (BUK)	omio)	4	
(3)	PAN HEAD SCREW M5 x 32MM	Canama-	4	
4	M4 ALLEN KEY (BALL SHAPE)LONG	L	1	
(5)	ICBC SCREW M6 X 35MM	0	4	
6	SPRING WASHER	0	4	
(7)	FLAT WASHER	0	4	
(8)	ADJUSTABLE SCREW	an()	4	

TEM	PART UST	
A	MIDOLE TOP	i
B	APRON APRON	2
©	LEG.	2
(D)	TABLETOP	1

CODING

- -1329014
- -1329015



ISO 9001:2015

nesthouz.com









