

CODING

-133055

-133056



ISO 9001:2015
Reg. No. 000435-1-2017-1-QMS

nuhoom.com

Read the instructions carefully. Remove all the wrappings , staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

CAUTION

KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

| ITEM | PHOTO | HAREWARE NAME | QTY |
|------|---|----------------|-----|
| (A) |  | JCBC M6 x 60mm | 8 |
| (B) |  | Flat Washer M6 | 8 |
| (C) |  | Allen Key M4 | 1 |

| ITEM | PARTS NAME | QTY |
|------|------------|-----|
| (1) | Table Top | 1 |
| (2) | Table Leg | 4 |

NANCY

CODING
-133055
-133056



ISO 9001:2015
Reg. No. 000435-1-NANCY-1-QMS

nuhoom.com

