## **DABNEY**

CODING -134032



ISO 9001:2015

#### fynd.

Read the instruction carefully. Remove all the wrapping material. Staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches

## CAUTION KEEP ALL THE PARTS OUT REACH OF CHILDREN

ITEM	РНОТО	HARDWARE NAME	QTY
A	0000000	Bolts M6x25	16
<u>B</u>	9	Washers M6 x 19	18
<u>C</u>	<b>O</b>	Lock washer M6 x 11	16
(D)		Allen key K4	1
F	•	Bolts M6x45	2

ITEM	РНОТО	PARTS NAME	QTY
1		Тор	1
2		Foot	2
3		Suport	1

# DABNEY \_\_\_\_

CODING -134032



ISO 9001:2015 Reg. No. 000435-1-MY-1-QMS

#### fynd.

