


CODING

-134098



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

nestnordic.com

Read the instruction carefully. Remove all the wrapping material , staples and straps from the carton . Refer to the hardware and furniture part list for guidance . Be sure that you have all the parts before you start assembling . Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches .

Caution


KEEP ALL PARTS OUT OF REACH OF CHILDREN.

ITEM	HARDWARE LIST	QTY
Ⓐ	JCBC SCREW M6 X 35MM 	12
Ⓑ	SPRING WASHER 5/16" 	12
Ⓒ	FLAT WASHER 5/16" 	12
Ⓓ	ALLEN KEY M5 	1

ITEM	PART LIST	QTY
①	BODY 	1
②	LEG 	2
③	CENTER PANEL 	1

CODING


-134098



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

nestnordic.com

1



2

