VANCE

COADING

-134111

-134112



ISO 9001:2015 Reg. No. 000435-1-MY-1-QMS

LUOOMa.com

Read the instruction carefully. Remove all the wrapping material, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to p revent from sc ratches.

CAUTION

KEEP ALL THE PARTS OUT OF REACH OF CHILDREN.

ITEM	РНОТО	HAREWARE NAME	QTY
1	0	PVC PLATE HOLDER	6

ITEM	РНОТО	PARTS NAME	QTY
Α	(m)	TABLE TOP (BIG)	1
В	(B)	TABLE TOP (SMALL)	1
С		LEG(BIG)	3
D		LEG (SMALL)	3

COADING

-134111

-134112



ISO 9001:2015 Reg. No. 000435-1-MY-1-QMS

LUOOMa.com



