

CODING

-134137




ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

fyndfurniture.com

Read the instruction carefully. Remove all the wrapping material , staples and straps from the carton . Refer to the hardware and furniture part list for guidance . Be sure that you have all the parts before you start assembling . Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches .

Caution

KEEP ALL PARTS OUT OF REACH OF CHILDREN.

ITEM	HARDWARE LIST	QTY
(A)	JCBC SCREW M6 X 35MM 	8
(B)	SPRING WASHER 5/16" 	8
(C)	FLAT WASHER 5/16" 	8
(D)	ALLEN KEY M5 	1
(E)	ASSEMBLY SCREW 	4
(F)	CAM 	4

ITEM	PART LIST	QTY
(1)	TOP 	1
(2)	CENTER 	1
(3)	LEG (LEFT) 	2
(4)	LEG (RIGHT) 	2

CODING

-134137



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

fyndfurniture.com

