

## CODING

- 1349032
- 1349033
- 124025



ISO 9001:2015  
Reg. No. 000435-1-MY-1-QMS

nesthouz.com

Read the instructions carefully. Remove all the wrappings, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

## CAUTION

KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	PHOTO	HAREWARE NAME	QTY
(A)		JCBC BOLT M6 X 80MM	9 (1+ EXTRA)
(B)		JCBC BOLT M6 X 50MM	6 (2+ EXTRA)
(C)		SPRING WASHER M6	15 (2+ EXTRA)
(D)		SCREW PIN 15 X 15MM	6 (2+ EXTRA)
(E)		ALLEN KEY M4 (BALL SHAPE)	1
(F)		WOOD DOWEL M10 X 30MM	4 (1+ EXTRA)
(G)		PVC STOPPER	4
(H)		SCREW 6 X 5/8	4

ITEM	PHOTO	PARTS NAME	QTY
(1)		TABLE TOP	1
(2)		TABLE LEG (L & R)	2
(3)		APPRON	1
(4)		LEG SUPPORTER	1

**CODING**  
- 1349032  
- 1349033  
- 124025



ISO 9001:2015  
Reg. No. 000435-1-MY-1-QMS

nesthouz.com

