

CODING

- 145071
- 145039







ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS



nuhoom.com

Read the instructions carefully. Remove all the wrappings, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

CAUTION

KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	HARDWARE LIST	QTY	SPARE QTY
(A)	JCBC SCREW M8 X 50MM 	8	
(B)	FLAT WASHER M8 	8	
(C)	SPRING WASHER M8 	8	
(D)	ALLEN KEY M5 	1	

ITEM	DESCRIPTION	QTY
(1)	TABLE TOP 	1
(2)	TABLE LEG 	4

CODING

- 145071
- 145039



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

nuhoom.com

1

