## **TORRELL**

CODING -146034



ISO 9001:2015

#### fynd.

Read the instruction carefully. Remove all the wrapping material. Staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches

### CAUTION KEEP ALL THE PARTS OUT REACH OF CHILDREN

ITEM	РНОТО	HARDWARE NAME	QTY
A	$\left\langle \begin{array}{c} \\ \\ \\ \\ \end{array} \right\rangle$	Key 17mm	1
B		Bolts (M10x70)	8
0	0	Flat washers (Ø10xØ25)	8

ITEM	РНОТО	PARTS NAME	SPARE QTY
1		Main body	1
2		Leg	4

# **TORRELL**

CODING -146034



ISO 9001:2015 Reg. No. 000435-1-MY-1-QMS

#### fynd.



