

CODING

-147009
-147010
-146116



ISO 9001:2015

Reg.No. 00435-1-MY-1-QMS

nesthouz.com

Read the instruction carefully. Remove all the wrapping material staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure you have all parts before you start assembling. Place all the wooden furniture part on a clean and flat surface, such as carpet or rubbermat to prevent scratches.

CAUTION

KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	PHOTO	HARDWARE NAME	QTY
Ⓐ		JCBB SCREW M8 x 70MM	8
Ⓑ		SPRING WASHER 5/16"	8
Ⓒ		FLAT WASHER 5/16"	8
Ⓓ		ALLEN KEY M5	1
Ⓔ		JCBC SCREW M6 x 60MM (BLK)	4
Ⓕ		SPRING WASHER 1/4" (BLK)	4
Ⓖ		JCBC SCREW M6 x 40MM	2
Ⓗ		SPRING WASHER 1/4"	2
Ⓘ		BARREL NUT M6 X 13MM	4
Ⓙ		ALLEN KEY M4 BALL SHAPE (LONG)	1

ITEM	PHOTO	PART NAME	QTY
①		TABLE TOP	1
②		BOTTOM SUPPORT	2
③		BOTTOM SUPPORT RAIL	1
④		TABLE LEG	4

CODING

-147009
-147010
-146116



ISO 9001:2015
Reg.No. 00435-1-MY-1-QMS

nesthouz.com

