**CODING** -151011



ISO 9001:2015

## fyndfurniture.com

Read the instructions carefully. Remove all the wrappings, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

## CAUTION KEEP ALL THE PARTS OUT OF CHILDREN'S REACH

ITEM	РНОТО	HARDWARE NAME	QTY
A		Bolts M6x20	12
B	0	Washers M6 x 19	12
<u>(C)</u>	<b>©</b>	Lock washer M6 x 11	12
(D)		Allen key K4	1
E		Felt	4

ITEM	РНОТО	PARTS NAME	QTY
1		Main Body	1
2		Metal leg	2

CODING -151011



ISO 9001:2015

## fyndfurniture.com







