

**CODING** 

- 152014
- 152015



ISO 9001:2015

## nesthouz.com

Read the instruction carefully . Remove all the wrapping material staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure you have all part before you start assembling. Place all the wooden furniture part on a clean and flat surface, such as carpet or rubbermat to prevent scratches.

## CAUTION KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	РНОТО	HARDWARE NAME	QTY
A		JCBC M6 x 45 mm	4
B	<b>6</b>	SPRING WASHER	4
(C)		WOOD DOWEL M10 X 30mm	6
D	O-TOTAL	CSK M4 x 32mm	12
E		ALLEN KEY M4	1
F		WOOD DOWEL M8 X 30mm	2

ITEM	РНОТО	PARTS NAME	QTY
1		TABLE PANEL	1
2		SIDE FRAME	2
3		SUPPORT RAIL	2
4		вох	1

CODING

- 152014
- 152015



ISO 9001:2015 Reg. No. 000435-1-MY-1-QMS

## nesthouz.com

