SPORTAGE WARRANTY & ASSEMBLY GUIDE

CODING

- -231132
- -231174



ISO 9001:2015

Read the instruction carefully. Remove all the wrapping material. Staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches

CAUTION KEEP ALL THE PARTS OUT REACH OF CHILDREN

ITEM	HARDWARE LIST		QTY
1	JCBC M6 x 20 mm	(i)	16
2	SPRING WASHER	٨	16
3	M4 ALLEN KEY (BALL SHAPE) LONG		1

ITEM	PART LIST		QTY
A	CUSHION BODY		1
В	Front leg		2
С	Back leg		2

CODING

- -231132
- -231174



ISO 9001:2015

fynd.

