ASSEMBLY GUIDE



CODING - 231264 - 231265



ISO 9001:2015

Read the instructions carefully. Remove all the wrappings, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

CAUTION KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITE M	рното	HAREWARE NAME	QTY
A	() and the second of the secon	Csk M4 x 32mm	16
B		Plastic plate	4

ITE M	рното	PARTS NAME	QTY
1		Body	1
2		Leg	4

ALTO





ISO 9001:2015 Reg. No. 000435-1-MY-1-QMS

nesthouz.com

