

CODING  
-231338



ISO 9001:2015  
Reg. No. 000495-1-MY-1-QMS

nesthouz.com

Read the instruction carefully. Remove all the wrapping material staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure you have all part before you start assembling. Place all the wooden furniture part on a clean and flat surface, such as carpet or rubbermat to prevent scratches.

**CAUTION**  
KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	PHOTO	HARDWARE NAME	QTY
(A)		JCBC M6 x 50mm + S/W M6 + F/W M6 x 13mm	4
(B)		JCBC M6 x 25mm + S/W M6 + F/W M6 x 13mm	4
(C)		ALLEN KEY M4	1
(D)		L BRACKET	4
(E)		CSK SCREW M3.5 x 12mm	8
(F)		WOOD DOWEL M8 x 25mm	2
(G)		WOOD BUTTON 14.5mm	4

ITEM	PHOTO	PARTS NAME	QTY
(1)		LEFT LEG FRAME	1
(2)		RIGHT LEG FRAME	1
(3)		FRONT STRETCHER (LONG)	1
(4)		BACK STRETCHER (SHORT)	1
(5)		BACK REST	1
(6)		CUSHION SEAT	1

CODING  
-231338



ISO 9001:2015  
Reg. No. 000435-1-MY-1-QMS

nesthouz.com

**1**

**ATTENTION:  
DO NOT FULLY  
TIGHTEN YET**

**2**

**ATTENTION:  
FULLY TIGHTEN  
ALL THE BOLTS**

**3**

**4**

**5**

Turn clockwise or anti-clockwise  
to adjust leg leveller.

**COMPLETED  
CHAIR ASSEMBLY.**