

CODING

-231369

-231370



ISO 9001:2015

## nestnordic.com

Read the instruction carefully. Remove all the wrapping material staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure you have all part before you start assembling. Place all the wooden furniture part on a clean and flat surface, such as carpet or rubbermat to prevent scratches.

## **CAUTION** KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	РНОТО	HARDWARE NAME	QTY
A		JCBC M6 x 50mm + S/W M6 + F/W M6 x 13mm	4
B		JCBC M6 x 70mm + S/W M6 + F/W M6 x 13mm	4
C		ALLEN KEY M4	1

ITEM	РНОТО	PARTS NAME	QTY
1		LEFT SIDE FRAME	1
2		RIGHT SIDE FRAME	1
3		FRONT STRETCHER	1
4		BACK STRETCHER	1
5		CUSHION SEAT	1



CODING -231369 -231370



ISO 9001:2015 Reg. No. 000435-1-MY-1-QMS

