# SPORTAGE WARRANTY & ASSEMBLY GUIDE

#### **CODING**

- -232062
- -232091



ISO 9001:2015

### fynd.

Read the instruction carefully. Remove all the wrapping material. Staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches

### **CAUTION** KEEP ALL THE PARTS OUT REACH OF CHILDREN

ITEM	HARDWARE LIST		QTY
1	JCBC M6 x 20 mm	<b>()</b>	16
2	SPRING WASHER	٨	16
3	M4 ALLEN KEY (BALL SHAPE) LONG		1

ITEM	PART LIST		QTY
А	CUSHION BODY		1
В	Front leg		2
С	Back leg		2

CODING

-232062





ISO 9001:2015

## fynd.





