ASSEMBLY GUIDE

CODING - 232168



ISO 9001:2015

nesthouz.com

Read the instructions carefully. Remove all the wrappings, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

CAUTION

KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	РНОТО	HAREWARE NAME	QTY
A		JCBC Bolt M6 X 50MM	4
B		ALLEN KEY M4	1
C	AUTOUT	CSK Screw M4 x 65 MM	3
D	A COMPANY AND A	CSK Screw M4 x 38 MM	4

ITEM	РНОТО	PARTS NAME	QTY
1		Back Rest	1
2		Cushion Seat	1
3		Right Arm Rest	1
4		Left Arm Rest	1
5		Apron	1

DZIRE

CODING - 232168



ISO 9001:2015 Reg. No. 000435-1-MY-1-OMS

nesthouz.com

