## **CALIBRA**

CODING 232198



ISO 9001:2015

## nesthouz.com

Read the instructions carefully. Remove all the wrappings, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

CAUTION KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	РНОТО	HAREWARE NAME	QTY
A	O management	JCBC SCREW M6x50MM	6
B	O man	JCBC SCREW M6x20MM	4
©	<b>&amp;</b>	CHIPBOARD SCREW M4x45MM	3
(D)		ALLEN KEY M4	1

ITEM	РНОТО	PARTS NAME	QTY
1		BACK REST	1
2		SEAT	1
3		APRON	1
4		LEG L/R	2

## **CALIBRA**

CODING 232198



ISO 9001:2015 Reg. No. 000435-1-MY-1-QMS

## nesthouz.com

