# **BALENO**

#### CODING

- 233209
- 233210



ISO 9001:2015

#### nesthouz.com

Read the instructions carefully. Remove all the wrappings, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

### CAUTION KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

| ITE M | РНОТО   | HAREWARE N AME      | QTY |
|-------|---------|---------------------|-----|
| A     |         | Leg                 | 4   |
| B     |         | M8 x 50mm JCBC Bolt | 19  |
| (C)   | <b></b> | Spring washer       | 19  |
| D     | 0       | Flat washer         | 15  |
| E     |         | M 5 Allen key       | 1   |

| ITE M | РНОТО | PARTS NAME        | QTY |
|-------|-------|-------------------|-----|
| 1     |       | Back rest         | 1   |
| 2     |       | Seat frame        | 1   |
| 3     |       | Arm - R           | 1   |
| 4     |       | Arm - L           | 1   |
| 5     |       | Back rail support | 1   |
| 6     |       | Back cushion      | 3   |
| 7     |       | Seat cushion      | 3   |

#### CODING

- 233209
- 233210



ISO 9001:2015 Reg. No. 000435-1-MY-1-OMS

## nesthouz.com











