CARTER.

CODING

- 241317
- 241318



ISO 9001:2015

nesthouz.com

Read the instructions carefully. Remove all the wrappings, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

CAUTION
KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	PHOTO	HARDWARE NAME	QTY
(4)		JCBC BOLT M6 X 80MM (BLK)	4 (+1 extra)
B	@	JCBB BOLT M6 X 20MM (BLK)	4 (+1 extra)
0		BARREL NUT 6 X 13MM	4 (+1 extra)
0	~uuuu0	PH M5 x 32MM (BLK)	6 (+2 extra)
Œ		WOOD DOWEL 10 x 30MM	4 (+1 extra)
Œ		ALLEN KEY M4 (BALL SHAPE)	1
<u>©</u>	()	ADJUSTABLE SCREW 6 X 16MM	4 (+1 extra)

ITEM	РНОТО	PARTS NAME	QTY
(1)		FRONT LEG	1
@		BACK LEG	1
3	0 0	CHAIR BACK	1.
4		SIDE STRECHER	2
⑤		CHAIR SEAT	Ĭ,


CODING

- 241317
- 241318



ISO 9001:2015 Reg. No. 000435-1-MY-1-OMS

nesthouz.com



2/2 nesthouz.com