

## CODING

- 241333
- 241331



ISO 9001:2015  
Reg. No. 000435-1-MY-1-QMS

nuhoom.com

Read the instructions carefully. Remove all the wrappings, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

## CAUTION

KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	PHOTO	PART LIST	QTY
1		Top Backrest	1
2		Backrest	1
3		Under Backrest	1
4		Backrest Leg (R)	1
5		Backrest Leg (L)	1
6		Backrest Leg Support	1
7		Side Rail (R)	1
8		Side Rail (L)	1
9		Front Leg	1
10		Wooden Slat / Cushion	1

NO	PHOTO	HARDWARE LIST	QTY
A		JCBC SCREW M6 X 50MM	10 PCS
B		SPRING WASHER	12 PCS
C		CSK SCREW M4 X 32MM	4 PCS
D		ALLEN KEY	1 PC
E		JCBC M6 X 40MM	2 PCS
F		WOOD DOWEL	4 PCS

## CODING

- 241333
- 241331



ISO 9001:2015  
Reg. No. 000435-1-MY-1-QMS

nuhoom.com

