

## CODING

- 241335
- 241334
- 241393



ISO 9001:2015  
Reg. No. 000435-1-MY-1-QMS





nuhoom.com

Read the instructions carefully. Remove all the wrappings , staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

## CAUTION

KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

NO	PHOTO	HARDWARE LIST	QTY
(A)		JCBC SCREW M6 X 50MM	6 PCS
(B)		SPRING WASHER	6 PCS
(C)		CSK SCREW M4 X 35MM	4PCS
(D)		ALLEN KEY	1 PC
(E)		WOOD DOWEL	4 PCS

ITEM	PHOTO	PART LIST	QTY
(1)		CHAIR BACK	1 PC
(2)		FRONT LEG	1 SET
(3)		SIDE RAIL	2 PCS
(4)		CUSHION SEAT	1 PC

## CODING

- 241335
- 241334
- 241393



ISO 9001:2015  
Reg. No. 000435-1-MY-1-QMS

nuhoom.com

