

## CODING

- 241339
- 241338
- 241394



ISO 9001:2015  
Reg. No. 000435-1-MY-1-QMS



nuhoom.com

Read the instructions carefully. Remove all the wrappings , staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

## CAUTION

KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

| NO  | PHOTO   | HARDWARE LIST        | QTY    |
|-----|---|----------------------|--------|
| (A) |  | JCBC SCREW M6 X 50MM | 12PCS  |
| (B) |  | SPRING WASHER        | 12 PCS |
| (C) |  | CSK SCREW M4 X 32MM  | 16PCS  |
| (D) |  | WOOD DOWEL           | 8 PCS  |
| (E) |  | ALLEN KEY            | 1 PC   |

| ITEM | PHOTO  | PART LIST             | QTY   |
|------|--|-----------------------|-------|
| (1)  |  | BACKREST              | 2 PCS |
| (2)  |  | SIDE RAIL             | 4 PCS |
| (3)  |  | FRONT LEG             | 2 PCS |
| (4)  |  | WOODEN SLAT / CUSHION | 2 PCS |
| (5)  |  | STRETCHER             | 4 PCS |

**CODING**

- 241339
- 241338
- 241394



ISO 9001:2015  
Reg. No. 000435-1-MY-1-QMS

nuhoom.com

