

CODING

- 241351


ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

nesthouz.com

Read the instructions carefully. Remove all the wrappings , staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

CAUTION

KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	PHOTO	HARDWARE NAME	QTY
(A)		JCBC BOLT M6 X 60MM (RB)	2 (+1 extra)
(B)		JCBC BOLT M6 X 45MM (RB)	4 (+1 extra)
(C)		JCBC BOLT M6 X 30MM (RB)	4 (+1 extra)
(D)		SPRING WASHER 5/16" (RB)	10 (+2 extra)
(E)		FLAT WASHER 6 X 13MM (RB)	6 (+2 extra)
(F)		SCREW PIN 15 X 15MM	4 (+1 extra)
(G)		PH M5 X 32MM (BLACK)	4 (+1 extra)
(H)		WOOD DOWEL M10 X 30MM	8 (+2 extra)
(I)		ALLEN KEY M4 (BALL SHAPE)	1
(J)		WOOD BUTTON BIG	4 (+1 extra)

ITEM	PHOTO	PARTS NAME	QTY
①		CHAIR LEG (L&R)	2
②		CHAIR BACK	1
③		FRONT RAIL	1
④		BACK RAIL	1
⑤		CHAIR SEAT	1

CODING
- 241351



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

nesthouz.com

