

CODING

- 241417
- 241289
- 241314
- 241439



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

nuhoom.com

Read the instructions carefully. Remove all the wrappings, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

CAUTION

KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	PHOTO	HARDWARE NAME	QTY
(A)		JCBC M6 x 25mm + S/W M6 + F/W M6 x 13mm	4
(B)		JCBC SCREW M6 x 50mm	4
(C)		BARREL NUT M6 x 13mm	4
(D)		ALLEN KEY M4	1
(E)		L BRACKET	4
(F)		CSK CB SCREW M3.5 x 12mm	8
(G)		WOOD DOWEL M8 x 25mm	2

ITEM	PHOTO	PARTS NAME	QTY
(1)		TOP REST UP	1
(2)		TOP REST DOWN	1
(3)		FRONT STRETCHER	1
(4)		BACK STRETCHER	1
(5)		RIGHT SIDE FRAME	1
(6)		LEFT SIDE FRAME	1
(7)		CUSHION SEAT	1

CODING

- 241417
- 241289
- 241314



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

nuhoom.com

