

CODING
-241499



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

LUOMA.COM

Read the instruction carefully. Remove all the wrapping material staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure you have all part before you start assembling. Place all the wooden furniture part on a clean and flat surface, such as carpet or rubbermat to prevent scratches.

CAUTION
KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

| ITEM | PHOTO | HARDWARE NAME | QTY |
|------|-------|---|-----|
| A | | JCBC M6 x 30mm + S/W M6 + F/W M6 x 13mm | 4 |
| B | | JCBC M6 x 50mm + S/W M6 + F/W M6 x 13mm | 2 |
| C | | JCBC M6 x 55mm + S/W M6 + F/W M6 x 13mm | 2 |
| D | | ALLEN KEY M4 | 1 |
| E | | L BRACKET | 4 |
| F | | PH SCREW M4 x 12mm | 8 |
| G | | WOOD DOWEL M8 x 25mm | 2 |

| ITEM | PHOTO | PARTS NAME | QTY |
|------|-------|------------------|-----|
| ① | | RIGHT SIDE FRAME | 1 |
| ② | | LEFT SIDE FRAME | 1 |
| ③ | | FRONT STRETCHER | 1 |
| ④ | | BACK STRETCHER | 1 |
| ⑤ | | TOP REST | 1 |
| ⑥ | | CUSHION SEAT | 1 |

CODING
-241499



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS



1

Front Stretcher has a small hole for identification.

2

**ATTENTION:
DO NOT FULLY
TIGHTEN THE BOLT**

3

Jcbc Bolt Fixing Step

**ATTENTION:
FULLY
TIGHTEN
THE BOLT**

4

**ATTENTION:
PLEASE FULLY
TIGHTEN THE
BOLT**

5

STEP 1

STEP 2

6

COMPLETED
CHAIR ASSEMBLY.