

CODING - 241590 - 241591 - 241589



ISO 9001:2015

nuhoom.com

Read the instruction carefully. Remove all the wrapping material, staples and straps from the carton. Refer to the hardware and furniture part list for guidan ce. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flast soft sureface , such and carpet or rubbermat to prevent from scratches.

CAUTION KEEP ALL THE PARTS OUT OF REACH OF CHILDREN

ITEM	РНОТО	HAREWARE NAME	QTY
1		JCBC SCREW M6 x 45MM	2
2	0)	JCBC SCREW M6 x 60MM	4
3		JCBC SCREW M6 x 80MM	4
4	0	FLAT WASHER M6	10
5	0	SPRING WASHER M6	10
6		ALLEN KEY M4	1

ITEM	РНОТО	PARTS NAME	QTY
Α		BACK	1
В		SEAT	1
С		LEG	2

SUZY

ASSEMBLY GUIDE

- CODING 241590 241591 241589



ISO 9001:2015 Rag, No. 000435-1-MY-1-QMS

nuhoom.com





