

CODING
- 241657
- 241658



ISO 9001:2015
Reg.No. 000435-1-MY-1-QMS

nuhoom.com

Read the instructions carefully. Remove all the wrappings, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

CAUTION
KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	PHOTO	HAREWARE NAME	QTY
A		M4 x 110mm ALLEN KEY.	1
B		M6 x 50mm JCBC BOLT	8
C		Spring Washer	8
D		Wood Dowel 8 x 30mm	4
E		Screw M4 x 32mm	4

ITEM	PHOTO	HAREWARE NAME	QTY
1		Side Frame L	1
2		Side Frame R	1
3		Back Frame	1
4		Side Rail R	2
5		Center Rail	1

NAZO

ASSEMBLY GUIDE

CODING
- 241657
- 241658



ISO 9001:2015
Reg.No. 000435-1-MY-1-QMS

nuhoom.com

