

CODING
-275006








ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS



Read the instruction carefully. Remove all the wrapping material. Staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches

CAUTION
KEEP ALL THE PARTS OUT REACH OF CHILDREN

ITEM	PHOTO	HARDWARE NAME	QTY
(A)		Bolts (M10x70)	8
(B)		Flat washers (\varnothing 10x \varnothing 22)	8
(C)		Wrench 17mm	1

ITEM	PHOTO	PARTS NAME	SPARE QTY
(1)		Bench Top	1
(2)		Leg	4

CODING
-275006



ISO 9001:2015

Reg. No. 000435-1-MY-1-QMS



1

