

CODING

-6567115



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

nesthouz.com

Read the instruction carefully. Remove all the wrapping material, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches.

CAUTION

KEEP ALL THE PARTS OUT OF REACH OF CHILDREN.

ITEM	HARDWARE LIST	QTY
(A)	RUBBER STOPPER (6/8 X 1 1/2") 	4
(B)	ALLEN KEY SCREW (M6 X 50) + HEX NUT 	4
(C)	RUBBER STOPPER 1" 	2
(D)	GOLD CAP B7 2" 	4
(E)	GOLD CAP G260 A 4/8" 	10
(F)	RUBBER STOPPER BOTTOM (2") 	4
(G)	ALLEN KEY M4 	1

CODING

-6567115



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

nesthouz.com

