

BUTTERCUP

WARRANTY & ASSEMBLY GUIDE

CODING
- 971012




ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

LUOMA.COM

Read the instruction carefully. Remove all the wrapping material, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches.

CAUTION
KEEP ALL THE PARTS OUT OF REACH OF CHILDREN.

ITEM	HARDWARE LIST	QTY
------	---------------	-----

ITEM	PART LIST	QTY
①	Mirror 	1

CODING
- 971012



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

LUOMA.COM

1

