

CODING

- 124039
- 124040
- 124081
- 124082



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

Read the instructions carefully. Remove all the wrappings , staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

CAUTION

KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	PHOTO	HAREWARE NAME	QTY
(A)		JCBC BOLT M6 X 30MM	2
(B)		PAN HEAD WOOD SCREW M4 X 16MM	20
(C)		ALLEN KEY M4 (BALL SHAPE)	1

ITEM	PHOTO	PARTS NAME	QTY
(1)		TABLE TOP	1
(2)		METAL LEG	2
(3)		METAL LEG SUPPORT	2
(4)		LEG SUPPORT WOODEN	4

CODING

- 124039
- 124040



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

1

