

CODING

-131131





ISO 9001:2015
Reg. No. 000435-I-MY-I-QMS

Read the instruction carefully. Remove all the wrapping material , staples and straps from the carton . Refer to the hardware and furniture part list for guidance . Be sure that you have all the parts before you start assembling . Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches .

Caution

KEEP ALL PARTS OUT OF REACH OF CHILDREN.

ITEM	HARDWARE LIST	QTY
Ⓐ	JCBC SCREW M6 X 35MM 	8
Ⓑ	SPRING WASHER 5/16" 	8
Ⓒ	FLAT WASHER 5/16" 	8
Ⓓ	ALLEN KEY M5 	1
Ⓔ	ASSEMBLY SCREW 	4
Ⓕ	CAM 	4

ITEM	PART LIST	QTY
①	TOP 	1
②	CENTER 	1
③	LEG (LEFT) 	2
④	LEG (RIGHT) 	2

CODING

-131131



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

