

CODING

- 132011



ISO 9001:2015
Reg. No. 009431-1-MY-1-QMS

Read the instruction carefully. Remove all the wrapping material, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches.

CAUTION

KEEP ALL THE PARTS OUT OF REACH OF CHILDREN.

ITEM	HARDWARE LIST	QTY
(A)	 4X15MM	5
(B)	 DIA 16MM	4
(C)	 DIA 8MM	4


ITEM	PART LIST	SPARE QTY
(1)	 MIRROR	1
(2)	 TABLE FRAME	1
(3)	 P3 LEG	1
(4)	 P4 LEG	1

CODING
- 132011




ISO 9001:2015
Reg. No. 090435 L-MY-1-QM2


1



2



3



4

