


CODING

142017




ISO 9001:2015
Reg. No. 000435-1-MET-1-QM01

Read the instructions carefully. Remove all the wrappings , staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

CAUTION

KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	PHOTO	HARDWARE NAME	QTY
(A)		JCBC M6 x 70mm	8
(B)		M6 Spring Washer	8
(C)		M6 Flat Washer	8
(D)		Allen Key M4	1

ITEM	PHOTO	PARTS NAME	QTY
(1)		Table Top	1
(2)		Table Leg	4


CODING

142017



ISO 9001:2015
Reg. No. 08405-1-MCY-1-QM0

1



2

