

CODING

-144093
-145175
-146147



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

Read the instructions carefully. Remove all the wrappings , staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

CAUTION

KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	PHOTO	HARDWARE NAME	QTY
(A)		JCBB BOLT M8 X 80MM (BLK)	8 PCS (+ 1 EXTRA)
(B)		SPRING WASHER 5/16" (BLK)	8 PCS (+ 1 EXTRA)
(C)		FLAT WASHER 5/16"	8 PCS (+ 1 EXTRA)
(D)		ALLEN KEY M5	1 PC
(E)		JCBC SCREW M6 X 80MM	12 PCS (+ 1 EXTRA)
(F)		SPRING WASHER 5/16"	12 PCS (+ 2 EXTRA)
(G)		FLAT WASHER 6 X 13MM	12 PCS (+ 2 EXTRA)
(H)		ALLEN KEY M4	1 PC

ITEM	PHOTO	PART NAME	QTY
(1)		TABLE TOP	1 PC
(2)		TABLE LEG	4 PCS

CODING
-144093
-145175
-146147



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

1

