

CODING:-  
- 230029  
- 230030  
- 230055  
- 230056



ISO 9001:2015  
Reg. No. 0004351-MY-1-QMS

Read the instruction carefully. Remove all the wrapping material, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches.

## CAUTION

KEEP ALL THE PARTS OUT OF REACH OF CHILDREN

| ITEM | PHOTO |                     | QTY   | ITEM | PHOTO | PARTS NAME | QTY   |
|------|-------|---------------------|-------|------|-------|------------|-------|
| (A)  |       | JCBC BOLTS M6 X 40M | 4 PCS | 1    |       | TABLE TOP  | 1 PC  |
| (B)  |       | CB SCREW M4 X 32MM  | 4 PCS | 2    |       | COLUMN     | 1 PC  |
| (C)  |       | FLAT WASHER 5/16    | 4 PCS | 3    |       | CROSSBAR   | 1 SET |
| (D)  |       | ALLEN KEY M4        | 1 PC  | 4    |       | FEET       | 4PCS  |
| (E)  |       | SPANNER             | 1 PC  |      |       |            |       |
| (F)  |       | ADJUST SCREW        | 4 PCS |      |       |            |       |
| (G)  |       | HEX NUT 5/16        | 4 PCS |      |       |            |       |

STEP 1

STEP 2

STEP 3

COMPLETED

CODING:-  
- 230029  
- 230030  
- 230055  
- 230056



ISO 9001:2015  
Reg. No. 00000000000000000000

nuhoom.com

Read the instruction carefully. Remove all the wrapping material, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches.

## CAUTION

KEEP ALL THE PARTS OUT OF REACH OF CHILDREN

| ITEM | PHOTO                |  | QTY   | ITEM | PHOTO | PARTS NAME          | QTY  |
|------|----------------------|--|-------|------|-------|---------------------|------|
| (A)  | JCBC BOLTS M6 X 50MM |  | 12PCS | 1    |       | Chair Back          | 1 PC |
| (B)  | JCBC BOLTS M6 X 40MM |  | 4PCS  | 2    |       | ARM SET             | 2PCS |
| (C)  | SPRING WASHER M6     |  | 12PCS | 3    |       | FRONT PANEL         | 1 PC |
| (D)  | ALLEN KEY M4         |  | 1PC   | 4    |       | SEAT CENTER SUPPORT | 1 PC |
| (E)  | CSK SCREW M4 X 32MM  |  | 34PCS | 5    |       | SEAT CORNER BLOCK   | 2PCS |
| (F)  | WOOD DOWEL M8 X 35   |  | 4PCS  | 6    |       | BACK PANEL          | 1 PC |
| (G)  | WOOD BUTTON          |  | 4PCS  |      |       |                     |      |

STEP 1

STEP 2

STEP 3

STEP 4

COMPLETED