

CODING

-231338

-231438



ISO 9001:2015
Reg. No. 000435-1-MTY-1-QM5

Read the instruction carefully. Remove all the wrapping material staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure you have all part before you start assembling. Place all the wooden furniture part on a clean and flat surface, such as carpet or rubbermat to prevent scratches.

CAUTION

KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	PHOTO	HARDWARE NAME	QTY
Ⓐ		JCBC M6 x 50mm + S/W M6 + F/W M6 x 13mm	4
Ⓑ		JCBC M6 x 25mm + S/W M6 + F/W M6 x 13mm	4
Ⓒ		ALLEN KEY M4	1
Ⓓ		L BRACKET	4
Ⓔ		PH CB SCREW M4 x 12mm	8
Ⓕ		DOWEL M8 x 25mm	2
Ⓖ		WOOD BUTTON 14.5mm	4

ITEM	PHOTO	PARTS NAME	QTY
①		LEFT LEG FRAME	1
②		RIGHT LEG FRAME	1
③		FRONT STRETCHER (LONG)	1
④		BACK STRETCHER (SHORT)	1
⑤		BACK REST	1
⑥		CUSHION SEAT	1

CODING
-231338
-231438



ISO 9001:2015
Reg. No. 000435-1-MY-1-QM5

