

CODING
231416




ISO 9001:2015
Reg. No. 00905-1-MY-1-QMS

Read the instructions carefully. Remove all the wrappings , staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

CAUTION
KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	PHOTO	HAREWARE NAME	QTY
Ⓐ		JCBB BOLT M8x25mm	8
Ⓑ		M5 ALLEN KEY	1

ITEM	PHOTO	PARTS NAME	QTY
①		CUSHION BACK	1
②		CUSHION SEAT	1
③		ARM L&R	2

CODING
231416



ISO 9001:2015
Reg. No. 000105-1-MTY-1-QMS

