

Cruiser

WARRANTY & ASSEMBLY GUIDE

CODING

- 232058
- 232059
- 232060



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

Read the instruction carefully. Remove all the wrapping material, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches.

CAUTION

KEEP ALL THE PARTS OUT OF REACH OF CHILDREN.

ITEM	HARDWARE LIST	QTY
(A)	Socket head screw 	12
(B)	Allen key 	1

ITEM	PART LIST	QTY
(1)		1
(2)	Front leg 	2
(3)	Back leg 	2

CODING

- 232058
- 232059
- 232060



ISO 9001:2015
Reg. No. 000435-1-MET-1-QM&S

1

