

CODING
233350







ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

Read the instructions carefully. Remove all the wrappings , staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

CAUTION

KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	PHOTO	HAREWARE NAME	QTY	
			3EL	2ECRT
Ⓐ		SOFA LEG	3	3
Ⓑ		JCBB BOLT M8x50MM	6	6
Ⓒ		FLAT WASHER	6	6
Ⓓ		ALLEN KEY M5	1	1
Ⓔ		SUPPORT LEG (200MM)	2	2

ITEM	PHOTO	PARTS NAME	QTY
①		SOFA 3EL	1
②		SOFA 2ECRT	1

CODING
233350



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

