



CODING
- 345082





ISO 9001:2015
Reg. No. 000405-1-2017-1-Q005


Read the instructions carefully. Remove all the wrappings , staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

CAUTION
KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.


ITEM	PHOTO	HARDWARE NAME	QTY
(A)		JCBC BOLT 1/4" x 1 9/16"	4
(B)		SPRING WASHER 1/4" x 1/2"	4
(C)		FLAT WASHER 1/4" x 3/4"	4
(D)		WOOD DOWEL 5/16" x 1 3/16"	4
(E)		ALLEN KEY 1/4" x 2 3/8"	1
(F)		TIPPING RESTRAINT KIT	1

ITEM	PHOTO	PARTS NAME	QTY
(1)		Bravon 1.6M Sideboard 191	1
(2)		Leg	4
(3)		Center Support Leg	2

CODING
 - 345082



ISO 9001:2015
 Reg. No. 000405-1-2017-1-Q002



CODING
- 345082



ISO 9001:2015
Reg. No. 120105-1-ART-1-001

3

