



CODING
- 355019



ISO 9001:2015
Reg. No. 00435-1-MY-1-QM8

Read the instructions carefully. Remove all the wrappings, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

CAUTION
KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.


HARDWARE			
A	MINI FIX	A1  A2  A3 	43 SETS
B	M8 X 30MM WOOD DOWEL		38 PCS
C	M6 X 50MM CSK CAP WOOD SCREW		8 PCS
D	ALLEN KEY M4		1 PC
E	M3.5 X 16MM C.B SCREW		116 PCS
F	STUD 192 WITH SCREW	F1  F2 	16 PCS
G	433 OVAL TUBE BRACKET		4 PCS
H	433 OVAL PAIP(971MM)		1 PC
I	433 OVAL PAIP(467MM)		1 PC
J	SOFT CLOSING 7/8 HINGES		12 PCS
K	864 PVC NAIL LEG BLACK (L)		6 PCS
L	HANDLE EM 0071		2 PCS
M	M3 X 12MM C.B SCREW		4 PCS

SELF-PREPARED TOOLS: Tools below are NOT included in package.


 SCREWDRIVER	 HAMMER
---	--

PART LIST		QTY
1	TOP PANEL	1 PC
2	BOTTOM PANEL	1 PC
3	SIDE PANEL (L)	1 PC
4	SIDE PANEL (R)	1 PC
5	CENTER PANEL	1 PC
6	MIDDLE PANEL (L)	2 PCS
7	MIDDLE PANEL (R)	2 PCS
8	BACK BONE (L)	2 PCS
9	BACK BONE (R)	2 PCS
10	BACK PANEL (L)	1 PC
11	BACK PANEL (R)	1 PC
12	DOOR PANEL (L)	1 PC
13	DOOR PANEL (R)	2 PCS
14	CABINET LEG	2 PCS
15	CENTER LEG	1 PC

ISO 9001:2015
Eng. No. 000435-1-MY-1-QMS




CODING
- 355019



ISO 9001:2015
Reg. No. 800435-1-MY-1-QMS


STEP 1

- Insert hardware **A1** onto panel (2), (6), (7), (8) and (9).
(Repeat 36 times.)
- Insert hardware **A2** onto panel (2).
(Repeat 1 times.)
- Insert hardware **B** onto panel (2), (6) and (7).
(Repeat 20 times.)




STEP 2

- Insert hardware **A2** onto panel (3) and (4).
(Repeat 24 times.)
- Insert hardware **B** onto panel (3) and (4).
(Repeat 4 times.)
- Assemble the hardware **G** onto panel (3) and (4) by using hardware **E**.
(Repeat 2 times for each hardware.)




STEP 3

- Insert hardware **A1** onto panel (14) and (15).
(Repeat 7 times.)
- Insert hardware **A2** onto panel (5) and (14).
(Repeat 18 times.)
- Insert hardware **B** onto panel (5), (14) and (15).
(Repeat 14 times.)
- Assemble the hardware **G** onto panel (5) by using hardware **E**.
(Repeat 2 times for each hardware.)




CODING
- 355019



ISO 9001:2015
Reg. No. 800435-1-MY-1-QMS


STEP 4

- Attach panel (14) to panel (15).
- Insert all hardware A2 into A1.
- Rotate all A1 until tight.
- Apply A3 onto all A1.
- (Repeat 2 times.)




STEP 5

- Attach panel (2) to panel (14) and (15).
- Insert all hardware A2 into A1.
- Rotate all A1 until tight.
- Apply A3 onto all A1.
- (Repeat 1 time.)




STEP 6

- Connect panel (2) to panel (5) by using hardware C and D.
- (Repeat 2 times.)




STEP 7

- Attach panel (6), (7), (8) and (9) to panel (5).
- Insert all hardware A2 into A1.
- Rotate all A1 until tight.
- Apply A3 onto all A1.
- (Repeat 16 times.)




STEP 8

- Attach panel (2), (6), (7), (8) and (9) to panel (3) and (4).
- Insert all hardware A2 into A1.
- Rotate all A1 until tight.
- Apply A3 onto all A1.
- (Repeat 24 times.)




STEP 9

- Insert the panel (10) and (11) along the slot.




CODING
- 355019



ISO 9001:2015
Reg. No. 800435-1-MY-1-QMS


STEP 10

- Connect panel (1) to panel (3), (4) and (5) by using hardware C and D.
(Repeat 6 times.)




STEP 11

- Assemble hardware K into panel (3), (4), (14) and (15) by using hardware E.
(Repeat 6 times for each hardware.)




STEP 12

- Insert hardware F1 into slot at panel (1), (2), (3) and (4).
- Assemble hardware F1 by using hardware F2.
(Repeat 16 times.)




STEP 13

- Attach hardware H and I to hardware G.



STEP 14


- Fix hardware J onto panel (12) and (13) by using hardware E.
(Repeat 2 times for each hardware.)
- Fix hardware L onto panel (13) by using hardware M.
(Repeat 2 times for each hardware.)



* In this step hardware G have been assembled.

STEP 15

- Fix hardware J into panel (3), (4) and (5) by using hardware E.
(Repeat 4 times for each hardware.)
- Tighten or loosen the screw to adjust position of panel (12) and (13).
(Do only when needed.)



* In this step hardware J have been assembled in panel (12) and (13).