

CODING
-5607015



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

Read the instruction carefully. Remove all the wrapping material, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches.

CAUTION
KEEP ALL THE PARTS OUT OF REACH OF CHILDREN.


ITEM	PART LIST	QTY
①	BASKET TRAY	4
②	STOPPER	4
③	METAL LEG	2

CODING
-5607015



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

1



BASKET TRAY

METAL LEG

STOPPER