

CODING
- 655034




ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

Read the instructions carefully. Remove all the wrappings , staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

CAUTION
KEEP ALL THE PARTS OUT OF CHILDREN'S REACH.

ITEM	HARDWARE LIST	QTY
Ⓐ	Allen key 5mm 	1
Ⓑ	Bolts (M6x10) 	12
Ⓒ	Allen key 4mm 	1
Ⓓ	Bolts (M6x40) 	16
Ⓔ	Flat washers (Ø8xØ18) 	16
Ⓕ	Bolts (M6x20) 	16
Ⓖ	Flat washers (Ø10xØ25) 	16
Ⓗ	Screw (M4x30) 	24


ITEM	HARDWARE LIST	SPARE QTY
1	Headboard -uper 	1
2	Footboard 	1
3	Side rail L+R 	2
4	Center rail 	1
5	Wooden bracket 	4
6	Leg 	4
7	Slat 	12

CODING
-655034




ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

1




Step 1:

2



Step 2:

3



Step 3: