

CODING

-655044

-656049



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

Read the instruction carefully. Remove all the wrapping material. Staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Be sure that you have all the parts before you start assembling. Place all the wooden furniture part on a clean and flat soft surface, such as carpet or rubbermat to prevent from scratches

CAUTION

KEEP ALL THE PARTS OUT REACH OF CHILDREN

ITEM	PHOTO	HARDWARE NAME	QTY
(A)		Allen key 5mm	1
(B)		Bolts (M6x10)	12
(C)		Allen key 4mm	1
(D)		Bolts (M6x40)	16
(E)		Flat washers (Ø8xØ18)	16
(F)		Bolts (M6x20)	16
(G)		Flat washers (Ø10xØ25)	16
(H)		Screw (M4x30)	24

ITEM	PHOTO	PARTS NAME	SPARE QTY
(1)		Headboard -uper	1
(2)		Footboard	1
(3)		Side rail L+R	2
(4)		Center rail	1
(5)		Wooden bracket	4
(6)		Leg	4
(7)		Slat	12

CODING
-655044
-656049



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

