

CODING
-656060



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

Read the instructions carefully. Remove all the wrappings, staples and straps from the carton. Refer to the hardware and furniture part list for guidance. Make sure that you have all the parts before you start assembling. Place all the wooden furniture parts on a clean, flat and soft surface, such as a carpet or rubbermat to prevent scratches.

CAUTION
KEEP ALL THE PARTS OUT OF CHILDREN’S REACH

ITEM	PHOTO	HARD WARE NAME	QTY
A		Bolt M6x12	12
B		Allen key K5	1
C		Screw Ø4x30	2

ITEM	PHOTO	PARTS NAME	QTY
1		HEADBOARD	1
2		FOOTBOARD	1
3		SIDE RAILS	2
4		METAL CENTER	1
5		SLATS	14

CODING
-656060



ISO 9001:2015
Reg. No. 000435-1-MY-1-QMS

